

Odwzorowuje funkcje pilota oryginalnego. Nie wymaga programowania, wystarczy włożyć baterie i jest gotowy do użycia.

Kompatybilny m.in. z:

- 6710900010A/E/F 6710300010G/J/S 6710900011W 6710T0008B/C/G 6710T00017M/Q/V 6710T00017B/H 6710T00079F 6710T00022D/F/S 6710V00091A/G/Z 6710V00124V 6710V00126L/Q 6710V00126R/M 6710V00138N/T/F 6710V00138L/M 6710V00141A/D/K 6710V00151S
- AKB14972914204 AKB33871407 AKB33871409 AKB33871410 AKB69680403 AKB69680404 AKB69680416 AKB72914009 AKB72914020 AKB72915207 AKB72915210 AKB72915211 AKB72976005
- MKJ30036801 MKJ32022805 MKJ32022814 MKJ32022826 MKJ32022835 MKJ32022838 MKJ33981404 MKJ33981406 MKJ33981410 MKJ33981413 MKJ33981422 MKJ37815702 MKJ39140804 MKJ39170805 MKJ39170806 MKJ40653802 MKJ40653806 MKJ40653807 MKJ40653831 MKJ42519601 MKJ42519604 MKJ42519605 MKJ49980313 MKJ61611303
- 105-2307J 105-209A/B/C/D/L/J/M 105-210A/E/F/J/M 105-21D/N/P/Q/R/Z 105-214C/G/L/S/PF 105-219A/D/L 105-224F/P 105-224G/F/P/Z 105-229Y/B/D 105-230A/C/D/F/G 105-230H/J/K/M/Y
- 6710900010S 6710900011N 6710900014A 6710T00017J 6710V000079A 6710V00007A/B/C/D 6710V00007Q/N/M/K 6710V00007H/W/V/T/S/Y 6710V000080C 6710V00008A/B/N/V 6710V00008C/K/T/W 6710V000140F 6710V00017E/F/G/H/M 6710V00018A 6710V00026C/A/D/H/J/ 6710V0027F/J/K
- ...i wiele innych modeli